


SHIMANO

STELLA S A-RB

STL-C5000XG



* (18735) Please send the equipment out to after-sales service for replacement of the roller clutch assembly.

Please note that the number of adjusting washers may not be the same as shown in the exploded views.

(51SF14H049X) (Adjustment will vary with each individual product.)

Part No.	Description	Part No.	Description	Part No.	Description		
RD 2110	Screw	RD16479	Worm Shaft Retainer	RD18747	Flange Water Proof		
RD 2409	Spacer	***	RD16480	O Ring	RD18751	Handle Knob Pipe	
RD 3538	Spool Support		RD16603	Ball Bearing	RD18758	Washer	
RD 3561	Screw		RD16616	Oscillating Pawl Cover	RD18762	Washer	
RD 4831	Ball Bearing	**	RD16618	Oscillating Pawl	RD18764	Handle Screw Cap	
RD 6008	Set Screw		RD16665	Line Roller Support	RD18968	Spool Washer	
RD 8013	Screw	****	RD16740	Drag Washer	RD18969	Rotor Brim	
RD 8074	Bearing Water Proof		RD16742	Drag Washer	RD18970	Bail Arm	
RD 8165	Washer		RD16838	Main Shaft Spacer	RD18971	Bail Spring Cover	
RD 8759	Click Pin		RD16931	Drag Washers Retainer	RD18972	Rotor Assembly	
RD 9833	Ratchet Spring		RD17267	Key Washer	RD18973	Bail Trip Lever	
RD 9847	Screw		RD17467	Bail Spring	RD18974	Bail Assembly	
RD 9849	Screw		RD17468	Bail Spring Guide B	RD18975	Bail Hold Support Guard	
RD 9856	Washer	***	RD17750	Bearing Housing	RD18977	Washer	
RD 9903	O Ring		RD17751	Ball Bearing	RD18978	Oscillating Guide A	
RD 9909	Eared Washer		RD17752	Washer	RD18979	Idle Gear	
RD 9912	Bearing Retainer		RD17760	Idle Gear B Shaft	RD18981	Side Cover Assembly	
RD 9931	Click Spring		RD18160	Bearing Spacer	RD18982	Handle Shaft Cover B	
RD 9968	O Ring	***	RD18200	Washer	****	RD18988	Oscillating Slider Bushing
RD11018	Ball Bearing	***	RD18358	Washer	**	RD18989	Main Shaft Assembly
RD11568	Screw		RD18448	Line Roller Set (With Bearing)	****	RD18990	Rear Protector
RD11578	Ball Bearing	***	RD18709	Drag Knob Assembly		RD18991	Worm Shaft
RD11646	Drag Click Ratchet		RD18711	Drag Click		RD18992	Oscillating Guide B
RD13241	Ball Bearing	**	RD18717	Screw		RD18993	Idle Gear (Small)
RD13269	Ball Bearing		RD18720	Screw		RD18997	Pinion Gear
RD13274	Ball Bearing	**	RD18724	Spring Guide A Support		RD18998	Drive Gear
RD13317	O Ring		RD18725	Bail Spring Guide A		RD18999	Handle Shank Assembly
RD13381	Ball Bearing		RD18726	Bail Spring Guide A Bush		RD19001	Idle Gear (Large)
RD14279	Washer		RD18728	Bail Trip Cam Bushing		RD19003	Spool Assembly
RD14300	Bearing Bushing		RD18729	Screw		RD19004	Handle Knob Assembly
RD14780	Screw		RD18731	Rotor Side Cover		RD19005	Handle Knob Seal
RD15489	Drag Click Spring		RD18732	Rotor Ring		RD19006	Handle Assembly
RD15718	Screw	**	RD18733	Friction Ring		RD19007	Body Assembly
RD15991	Rotor Nut Lock Plate		RD18734	Screw			
RD15992	Rotor Nut		RD18735	Roller Clutch Assembly		RD 9811	Reel Seat Spacer (accessory)
RD16380	Key Washer		RD18736	O Ring			
RD16426	Screw		RD18737	Roller Clutch Inner		PK 0456	Gear Set
RD16451	Screw		RD18738	Bearing Retainer		PK 0454	Bearing Set
RD16465	Handle Shaft Seal		RD18739	Washer	**/*	PK 0455	Oscillation Set
RD16478	Screw		RD18746	Bail Trip Strike		PK 0450	Line Roller Set