


Battery Mount
BM-E8030-A
BM-E8030-B



ITEM NO.	SHIMANO CODE NO.	DESCRIPTION
1	Y7GS00090	Bracket Fixing Screw (M6 x 10)
2	Y7GS98010	Upper Mount Unit
3	Y7GS00100	Upper Base Fixing Screw A (M5 x 18)
4	Y7GS00110	Upper Base Fixing Screw B (M4 x 8)
5	Y7GS98020	Spring Unit & Fixing Screw (M3 x 4)
6	Y7GS00230	Stopper Screw (M4 x 5)
7	Y7GS00200	Lower Mount Rubber L
8	Y7GS00190	Lower Mount Rubber R
9	Y7GS00350	Lower Bracket Fixing Screw (M6 x 12)
10	Y7GS00220	Lower Bracket Rubber B
11	Y7GS00210	Lower Bracket Rubber A
	Y13000050	TL-BME04 Battery Mount Setting Tool
*	Y13000070	TL-BME05 Battery Mount Setting Tool

Jul.-2020-4530A
 © Shimano Inc. I

Specifications are subject to change without notice.

SHIMANO